

LG HI-MACS®
Acrylic Solid Surface

Volcanics LG HI-MACS

LG HI-MACS®
Acrylic Solid Surface

CARE AND MAINTENANCE INSTRUCTIONS



FEATURES AND BENEFITS

- Seamless joins
- Design flexibility
- Infinite variety of edge treatments, inlays, splashback and sink mounting options
- Repairable if scratched or chipped
- Non-porous – maintaining a life-long hygienic surface
- Acrylic resins add extra strength
- 10 year limited warranty

REPAIRING SCRATCHES

To remove superficial scratches, rub a scouring pad (Chux All Purpose Scrub Sponge or Vileda Active Scourer) in a circular motion until the scratches are removed. Clean the area thoroughly with a general-purpose cleanser such as Ajax Spray n' Wipe and let dry. To effectively remove deep scratches we recommend you contact your certified LG HI-MACS® installer. They will offer the expertise to restore your LG HI-MACS® surface.

To provide added protection for granite colours or if an additional sheen is desired, apply a non-wax polish cleaner to a dry surface and wipe with a clean, dry cloth. Wipe your LG HI-MACS® surface dry using another clean cloth. We recommend using Mr Sheen Waterguard or Kiwi Shine as your polish.



LG Chem

LG Chem prides itself on quality assured manufacturing processes and

innovations in new technology. Following the care and maintenance instructions provided will ensure that your LG HI-MACS® surface continues to look as attractive as the day it was installed. LG Chem supports the quality of LG HI-MACS® surfaces with a 10 year limited warranty.

LG HI-MACS
10-Year
Limited Warranty

GUNNERSEN TIMBERMARK PTY LTD
ABN 35 004 051 003

ADELAIDE (08) 8359 1660 BRISBANE (07) 3277 6188 CAIRNS (07) 4035 3955
MELBOURNE (03) 9647 9911 NEWCASTLE 1800 451 115 PERTH (08) 9356 9911
SYDNEY (02) 9725 2300 TOWNSVILLE (07) 4779 0877

NEW ZEALAND 0800 448 663
www.gunnersens.com.au

gunnersen 
inspirations

HIMAC CARE 0605




THE FUTURE OF SURFACES

LG HI-MACS® offers total design freedom in its ability to create seamless stretches of bench tops, vanities or splashbacks. Available in a range of solid colours, quartz and granite effects, LG HI-MACS® may be crafted to achieve the sharpest lines or the softest curves.

LG HI-MACS® not only provides design flexibility, but offers a number of maintenance advantages as well. This non-porous material is both stain and impact resistant, providing greater durability than traditional benchtop materials. LG HI-MACS® is also repairable, so that scratches, chips or any damage inflicted over time may be removed and your surface restored to its original finish.

 **LG Chem**

gunnersen 
inspirations



LG HI-MACS® FINISHES

The final finish of your LG HI-MACS® surface will be determined by yourself and your certified fabricator. Your choice may be a matt, satin, semi-gloss or high-gloss finish. The finish you have selected will also determine how you care for the surface to retain its original finish.

Matt finishes are a low sheen, a soft finish that is recommended for light to medium colours. It is a low maintenance finish that is suitable for everyday work surfaces.

Satin finishes have a slightly higher sheen than matt and are recommended for darker colours. These finishes require moderate maintenance.

Semi-Gloss finishes are a higher gloss than satin. This is a high maintenance finish that is not recommended for kitchen benchtop applications. Semi-gloss finishes are recommended for vertical applications such as splashbacks or low wear horizontal surfaces (i.e. work stations) and require the services of a qualified fabricator to renew the finish.

High-Gloss finishes provide a mirror sheen and require a high degree of care. Recommended for vertical applications only, high-gloss requires the services of a qualified fabricator to renew the finish.

PRODUCT CARE

To avoid damaging your LG HI-MACS® surface:

- Do not place hot cookware directly onto LG HI-MACS® surfaces; always use a trivet under hot pans and heated appliances such as crock-pots and electric frying pans.
- Do not cut food directly on LG HI-MACS® surfaces; always use a chopping board to protect the surface.
- Do not use abrasive scouring pads for everyday cleaning. Only use a scouring pad on matt finishes to remove extremely stubborn stains or scratch marks. We recommend using Chux All Purpose Scrub Sponge or Vileda Active Scourer.
- Once a scouring pad has been used on a matt surface, apply a mild cream abrasive cleanser to the entire area and blend the scrubbed area into the surface rubbing in a circular motion with a soft cloth. We recommend using Jif or Ajax cream cleansers.
- Although minor cuts and scratches on LG HI-MACS® surfaces can be repaired, deep cuts will require the services of a professional fabricator.
- Strong acids such as those found in drain cleaners and oven cleansers should be used cautiously around your LG HI-MACS® surface. If these items are accidentally spilled, wipe them up at once. Some of these items, when left on the surface may cause whitening, which can be difficult to remove.

CLEANING

It is always best to wipe up spills as they occur on any surface, even a non-porous material such as LG HI-MACS®.

For everyday cleaning we recommend that you maintain the surface by wiping with a damp cloth and a good quality general purpose cleanser. We recommend Ajax Spray n' Wipe. Rinse well to remove any fats or oils.

For more stubborn stains on a matt finish a mild cream abrasive cleanser such as Jif or Ajax Cream Cleanser may be used on a damp LG HI-MACS® surface. Let the cleanser settle for a few minutes before using a soft cloth to rub in a circular motion, then rinse and dry the surface.

Periodically it may be helpful to go over the entire surface in a circular motion with our recommended mild cream abrasive cleanser to maintain a uniform appearance.

STAIN REMOVAL

While most everyday spills can be removed using a damp cloth and detergent, more stubborn stains such as food dye, tea and fruit drinks may require more rigorous cleaning methods. These items can be removed using bleach diluted 1:1 (1 part water: 1 part bleach) followed by a general purpose cleanser (Ajax Spray n' Wipe) however, bleach should only come in contact with the surface for a maximum of two minutes. On a matt finish, if you prefer, you may scrub with our recommended scourer (Chux All Purpose Scrub Sponge or Vileda Active Scourer) and a mild cream abrasive cleanser (Jif or Ajax Cream Cleanser).

STAIN RESISTANCE	
Stain	Result
Coffee	Easily removed with water
Distilled Liquor	
Edible Oil	
Iodine Fluid (10%)	
Milk	
Scotch	
Tea	Removed with neutral detergent*
Urine	
Water Marking Pen (Black)	
Crayon	Removed with cleanser^
Lipstick	
Water Marking Pen (Red)	Removed with cleanser^
Eye Brow Pencil	
Oil Marking Pen	

* eg Ajax Spray n' Wipe ^ eg Ajax Cream Cleanser

BURNS

While your LG HI-MACS® surface will not burn, should a lighted cigarette accidentally come in contact with the surface it may leave a nicotine stain or scorch mark. These stains can be removed by cleaning with a mild cream abrasive cleanser (Jif or Ajax Cream Cleanser) and buffing in a circular motion with a scouring pad (Chux All Purpose Scrub Sponge or Vileda Active Scourer).